

**HT300iw**  
**HT400iw**  
**HT800iw**  
owner's manual



analog and digital systems

# table of contents

introduction .....	1
cautions .....	1
features .....	1-2
installation precautions and tips .....	3
general mounting suggestions .....	3
rewiring .....	3
preparing the wall or ceiling cutout .....	4
final installation .....	4-5
custom painting .....	6
operation .....	6
specifications .....	7
warranty information .....	8

## introduction

Congratulations, and thank you for purchasing an a/d/s/ Home Theatre in-wall speaker system. The HT-series offer the perfect combination of style and performance to meet the most exacting audio and interior design standards. The proprietary driver design and computer-optimized crossover networks result in a smooth, flat frequency response, which in turn yields exceptional imaging and superb transient impact. The bass response and acoustic output capabilities of your HT series speakers are remarkable for units of such compact dimension. a/d/s/ Home Theatre speakers are the ultimate match for your discerning taste and lifestyle.

Be sure to save your sales receipt. It is your best record of the date of purchase, which is required for warranty service.

Read and follow all cautions, warnings and notes.

## cautions

To reduce the risk of electric shock, do not remove any parts of the speaker. There are no user serviceable parts inside. If service is required have it performed by a qualified service professional.

### **WARNING**

To prevent fire or shock hazard, do not expose the speakers to rain or submerge in water. The speakers should be situated away from heat sources such as radiators, heat registers, stoves or other heat sources.

Be sure all the components in the system are turned off while making audio and power connections.

## features

### **tweeter**

The HT series incorporates the use of a 1" copolymer dome tweeter with a Ferrofluid™ damped voice coil.

### **tweeter protection**

A solid state device reduces power to the tweeter when the loudspeaker is operated at unsafe power levels. It resets automatically when power is reduced to a safe level. Note: the tweeter protector provides a significant level of protection. However it does not guarantee that the tweeter cannot be damaged. Always be careful when operating the speakers at a high volume level.

### **high frequency contour switch**

A 3-position switch located on the tweeter plate serves as a high frequency contour control. The upper position offers a “normal” response suitable for most applications. The bottom position provides the most output and is recommended for off-axis listening or if the speakers are mounted very high. The center position provides the least and is recommended for reflective “bright” rooms. The upper position is the best starting point. Due to room acoustics and/or personal preference, you may prefer either of the other positions. Be sure to try all of these positions and decide on your preference before installing the grills. If you find it necessary to re-adjust the tweeter levels after the grills have been installed, please follow the removing the grille section on page 6.

### **woofer**

The HT series incorporates the use of a 5 1/4” woofer with a proprietary diaphragm made from a spherical inverted dome sandwiches to a copolymer cone, and utilizing a strontium ferrite magnet structure for well-damped, extended bass.

### **advanced industrial design**

In the world of in-wall speakers, most competing products can be categorized by their incredible degree of similarity. Regardless of the manufacturer, product offerings are limited to the same style of molded plastic chassis, the same types of mounting systems, similar drivers and the same limited performance capability. The HT series is a striking exception to this trend. Using the most advanced injection-molded driver technology available, it outperforms all others in its category. Attractively styled in a neutral off-white finish, it can be painted to perfectly match any wall.

### **aluminum extrusion mounting side-rails**

The advantage to this design is an incredibly rigid, durable mounting system that runs the entire length of the speaker from top to bottom. The mounting brackets do the same. As a result, the speaker is tightened to the wall over the full length of both of its sides.

### **quick & easy post-construction installation**

Thanks to the aluminum extrusion mounting side-rails, installation couldn’t be easier. Cut out the hole, insert the speaker, and tighten the screws. That’s all there is to it.

### **engineered for critical music listening**

While it is believed by many that in-walls do not do the best job of reproducing audio, a/d/s/ pushed the envelope in engineering this line of in-walls. From beginning to end, the HT series was engineered to deliver the best possible sonic reproduction.

### **ready for home-theatre entertainment**

a/d/s/ Home Theatre in-wall speakers are now video-shielded, making them the perfect candidates for a high-quality home-theatre system without having to use more intrusive bookshelf speakers.

### **d’Appolito array (HT400iw & HT800iw only)**

The d’Appolito array offers symmetrical and uniform dispersion making it possible for horizontal or vertical installation adding appeal for the home-theatre enthusiast.

### **“2 1/2-way” crossover (HT800iw only)**

The crossover was designed using all high quality components to create smooth acoustic slopes, while the “2 1/2-way tuning” helps to add crisp, clean bass. The two center woofers and tweeter perform exactly as the HT400iw creating a complete 2-way system. The two outside drivers are responsible only for the reproduction of low frequencies helping to augment the bass output.

## installation precautions and tips

Please read these instructions completely for the best enjoyment of your HT Series speakers.

- When you cut into the wall to install the speaker, do not cut through the facing or insulation that may be behind the wall. This facing is a moisture barrier. Use duct tape or wide vinyl tape to seal any cuts.
- Keep debris and loose material away from the installation location. Do not allow debris to get in the openings of the woofer basket. Debris and loose material can cause buzzing or rattling, and can damage the woofer cone. Install plastic or fiberglass screening above the speaker to keep debris away. Handle the speaker carefully.
- Do not let anything touch the speaker cone or dome. Do not clean the speaker with paint thinner or any solvents.
- Consider the services of a professional custom installer. If you have any doubts about your own abilities, it is better not to risk damaging your walls or ceilings, electrical wiring, ventilation ducts or plumbing.
- Work with good quality, correct tools. This will save you time and assure superior results.
- Allow sufficient clearance.
- When using speakers outdoors, locations should be sheltered from direct sunlight, rain or snow. Direct exposure will shorten product life.
- Combined impedance for speakers connected to each channel should be at least 4 ohms. This is the minimum impedance tolerated by most amplifiers. Check with your dealer before wiring multiple speaker pairs.

## general mounting suggestions

Avoid placing the speaker within two feet (0.6 meters) of a corner. The acoustic reflections from surfaces near the speakers can detract from the sound quality. Do not place the speaker behind heavy fabrics; if you cannot see through a fabric, you cannot hear through it.

The in-wall speakers are designed for "infinite baffle" operation. The area behind the speaker installation should be at least one-half cubic foot in volume to ensure proper performance. If the area is too small it will limit bass response and cause a peak in the mid-bass range.

## prewiring

- Check local building and electrical codes for compliance of the speaker wire.
- Use stranded wire of at least 16 gauge; for runs over 100 feet, it is preferable to use 14 gauge wire.
- Use only insulated staples or nylon tie straps to secure wiring within the wall to avoid shorts.
- Do not stretch the wire as it is being routed. This could create future (and costly) problems.
- Leave about 2-3 feet of free wire at both ends. Cutting excess wire is better than splicing.
- Always "home run" wires: run a continuous wire from each speaker directly to the source location. Do not connect speakers together any other way for easier diagnosis of faulty wire or speaker problems.
- Wire speakers in phase with the same polarity. Attach positive (+/red) and negative (-/black) terminals consistently.
- Combined impedance for speakers connected to each channel should be at least 4 ohms. This is the minimum impedance tolerated by most amplifiers. Check with your dealer before wiring.

## preparing the wall or ceiling cutout

Confirm there is at least 1" between the final cutout and nearby studs or joints for positioning mounting hardware. Temporarily fasten the stiff paper template (supplied) to the wall with thumbtacks. Carefully trace around the perimeter with a pencil. Before making the final cutout of the entire hole, first make a small 4-inch "test" cutout in the center of your penciled outline. Reach your hand inside to verify that studs are outside the outline. This is an important step, since stud finders are not infallible.

To cut the actual hole, first score wallboard with a sharp knife; then use a keyhole saw to complete the cut. Remove remaining debris from the edges. Hold the speaker up to the cutout to make sure it inserts easily without forcing.


At this point, it is a good idea to secure the speaker wire to a stud near the cutout so its own weight will not tug on the terminals of the speaker after it is connected. This will also prevent you from losing the wire in the wall. Before attaching the wire, make sure the speaker wire runs through, not around, the metal mounting bracket.

## final installation

1. Use the supplied cut-out templates to outline the mounting holes to be cut in the wall. Be sure the intended hole is square and plumb.  
Remove the perforated section out of the center of the template. Save this section, it will serve as  
  - a painting mask if you wish to paint the speaker in the wall. Use the inside edge of the remaining section of the template to mark the hole size
2. Cut the hole.
3. Route the speaker wire from the amplifier to the speaker installation location. Secure the wires to prevent them from falling into the wall before the speaker is mounted.
4. Adhesive-backed foam strip-gaskets are supplied with the packing materials. These will be used to line the back of the mounting collar flange. Remove the speaker from the corrugated shipping sleeve. Peel the backing from the foam strip-gaskets and place them along the back of the mounting collar flange. Cut them to size if necessary. Be sure to butt the strips up against each other to prevent possible air leakage. Once the strips are positioned properly, press them firmly into place. NOTE: this step is not necessary if you are installing the speaker into sheet-rock. Sheet-rock is soft enough to compress and naturally seal the gap.
5. Separate the two wire conductors from each other. Strip away approximately 1/4" of insulation from each of the wire conductors. Twist the strands together into neat bundles.
6. Push the positive (+/red) terminal to open the wire hole. Insert the positive conductor and release the terminal to lock the wire into place. Be sure not to insert the conductor too far causing the terminal to lock down on the insulation instead of the wire strands. Perform this same task for the negative (-/black) terminal as well.


7. Insert the speaker assembly on an angle so that one of the mounting brackets enters the opening first. (fig. 1)

fig1




8. Turn the speaker toward the wall so that the other mounting bracket enters the mounting hole and the speaker is seated on the wall. (fig. 2)

fig2



9. Hold the speaker in place in the mounting hole and begin tightening the mounting screws to draw the mounting bracket against the backside of the wall. Gradually tighten the screws, moving from one to another, until the speaker is firmly clamped in place. (fig. 3)

fig3



## removing the grille

Should it be necessary to remove the grille, insert an awl or other pointed tool into a grille hole near the corner. Gently lift the grille out of the speaker frame. Repeat this procedure at each corner of the grille, gradually lifting the corners of the grille until it is removed. Be careful not to allow anything to touch the woofer cones or tweeter domes while the grille is removed.

## custom painting

- Paint the speaker frame and grill before mounting to the wall; paint grill and frame separately.
- Before painting, mask the recessed area of the speaker to completely protect the speaker drivers.
- After painting the grill, gently blow through its perforated holes to prevent paint clogging.

## operation

### checking the system

Listen carefully to each speaker. If you hear buzzing or rattling noises, remove the speaker and check for a speaker wire or other objects touching the speaker assembly. When you are satisfied with the installation press the grills into place.

## specifications

	<b>HT300iw</b>	<b>HT400iw</b>	<b>HT800iw</b>
<b>Mounting hole</b>	6 3/8" x 9 1/8"	6 3/8" x 14 7/8"	6 3/8" x 26 1/2"
<b>Depth from front of wall</b>	3 1/4"	3 1/4"	3 1/4"
<b>Overall dimensions</b>	7 1/4" x 10 1/8"	7 1/4" x 15 7/8"	7 1/4" x 27 1/2"
<b>Power range (RMS watts)</b>	15-80	15-100	15-150
<b>Impedance</b>	4 ohms	8 ohms	4 ohms
<b>Frequency response (Hz)</b>	53-20k	45-20k	40-20k
<b>Sensitivity 1W/1M (dB)</b>	87dB	89dB	91dB
<b>Woofer</b>	5 1/4"	6 1/2"	8"
<b>Tweeter</b>	1" dome	1" dome	1" dome
<b>Crossover frequency (Hz)</b>	2.6k	2.4k	2.4k
<b>Crossover slope (dB/oct)</b>	12	12	12

(Specifications subject to change without notice)



# warranty information

## LIMITED TWO YEAR CONSUMER WARRANTY

Directed Electronics, Inc. promises to the original purchaser, to replace this product should it prove to be defective in workmanship or material under normal use, for a period of two years from the date of purchase from the dealer as indicated by the date code marking of the product **PROVIDED** the product was installed by an authorized Directed dealer. During this two-year period, there will be no charge for this replacement **PROVIDED** the unit is returned to Directed, shipping pre-paid. If the unit is installed by anyone other than an authorized Directed dealer, the warranty period will be one year from the date of purchase by the dealer as indicated by the date code marking of the product. This warranty is non-transferable and does not apply to any unit that has been modified or used in a manner contrary to its intended purpose, and does not cover damage to the unit caused by installation or removal of the unit. During this one-year period, there will be no charge for this replacement **PROVIDED** the unit is returned to Directed, shipping pre-paid. This warranty is void if the product has been damaged by accident or unreasonable use, neglect, improper service or other causes not arising out of defects in materials or construction. Units which are found to be damaged by abuse resulting in thermally damaged voice coils are not covered by this warranty but may be replaced at the absolute/sole discretion of Directed. **ALL WARRANTIES INCLUDING BUT NOT LIMITED TO EXPRESS WARRANTY, IMPLIED WARRANTY, WARRANTY OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, AND WARRANTY OF NON-INFRINGEMENT OF INTELLECTUAL PROPERTY ARE EXPRESSLY EXCLUDED TO THE MAXIMUM EXTENT ALLOWED BY LAW, AND DIRECTED NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO ASSUME FOR IT ANY LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT. DIRECTED HAS ABSOLUTELY NO LIABILITY FOR ANY AND ALL ACTS OF THIRD PARTIES INCLUDING ITS AUTHORIZED DEALERS OR INSTALLERS.** Unit must be returned to Directed, postage pre-paid, with bill of sale or other dated proof of purchase bearing the following information: consumer's name, telephone number, and address, authorized dealer's name and address, and product description. Note: This warranty does not cover labor costs for the removal and reinstallation of the unit. **IN ORDER FOR THIS WARRANTY TO BE VALID, YOUR UNIT MUST BE SHIPPED WITH PROOF OF INSTALLATION BY AN AUTHORIZED DIRECTED DEALER. ALL UNITS RECEIVED BY DIRECTED FOR WARRANTY REPAIR WITHOUT PROOF OF DIRECTED DEALER INSTALLATION WILL BE COVERED BY THE LIMITED 1 YEAR PARTS AND LABOR WARRANTY.** **Note:** This warranty does not cover labor costs for the removal and reinstallation of the unit. **BY PURCHASING THIS PRODUCT, THE CONSUMER AGREES AND CONSENTS THAT ALL DISPUTES BETWEEN THE CONSUMER AND DIRECTED SHALL BE RESOLVED IN ACCORDANCE WITH CALIFORNIA LAWS IN SAN DIEGO COUNTY, CALIFORNIA.**

## declaration of conformity

**manufacturer name:** Directed Electronics Inc.  
**manufacturer address:** One Viper Way  
Vista, California 92083

declares, that the product:

**product name:** HT300iw  
HT400iw  
HT800iw

conforms to the following standards:

EN55013  
EN55020



Designed and Engineered in the USA by  
***Directed***  
ELECTRONICS, INC.

Directed Electronics, Inc. All rights reserved G39556/61/71 10-02